

How to Form and Install your Heavy Duty Root Guard Gopher Wire Basket



1
Pull open green-painted top of basket at side seams



2
Flatten out bottom fold



3
Bend side seams flat against bottom



4
Finish rounding out the sides & bottom of basket



5
Install basket in pre-dug hole
We recommend leaving the top green-painted edge above ground to keep gophers from getting inside basket.



6
Backfill, being careful to eliminate any air spaces & water